
Before using this unit, carefully read the sections entitled: "Connection Precautions" and "Battery Swap Manual"


#### **Main Features**

- High-quality transparent booster pedal.
- Increases output volume while preserving tonal fidelity, adding depth and dimension to your tone.
- Features an output level indicator that remains active in both Boost and Bypass modes.

## **Panel Description**



### **Battery Swap Manual**



- 1. Parallelly draw out battery compartment.
- 2. Remove old battery, disconnect battery buckle clip.
- 3. Carefully observe the battery polarity (+ and -) before connecting the battery buckle clip. Connect new battery with battery buckle clip, put new battery in the compartment.
- 4. Parallelly draw in battery compartment, the magnet will help attach on the body.
- \*Tip: you can store your picks and other small stuff in the compartment.

# **Connection Precautions**

- Lower the volume and disconnect power to prevent misuse and equipment failure.
- Once the connections are correctly finished, please follow the subsequent steps to turn the power back on. Failure to do so may result in misuse or equipment failure
  - \*To power on: Connect the guitar amplifier to power last.
  - \*To power off: Disconnect the guitar amplifier from power first.
- When the unit is powered ON, the indicator light displays the effect's current status;
  - \*Indicator ON: Effect is active.
  - \*Indicator OFF: The unit is in bypass mode.

# **Battery Usage**

- This unit does not include a battery. Please use a 9V battery or an optional compatible power adaptor.
- If the battery power is low, the sound may become distorted. This is normal and does not indicate a malfunction. Replace the battery or connect a power adaptor.
- Always lower the volume before turning the pedal on or off. Some noise may still be heard during switching; this is normal and does not indicate a fault
- When operating on battery power, a dim indicator light means the battery is nearly depleted.
  Replace it promptly to avoid signal interruption.
- To prevent unnecessary battery drain, switch the pedal off when not in use.

## **Main Specifications**

| Maximum Gain                  | 20dB, can be increased by another 3dB<br>through the internal switch | Power Supply                 | Carbon Battery (9 V, 6F22)<br>Alkaline Battery (9 V, 6LR61)<br>Power Adapter (self-supplied)<br>9V Rechargeable Battery (GIGAGAIN MIB09,<br>sold separately) |
|-------------------------------|--|------------------------------|--|
| Maximum Output Level          | 0dBu   |                              |  |
| Input Impedance               | 1ΜΩ  |                              |  |
| Output Impedance              | 10ΚΩ   | Dimensions                   | 116*63*37 (mm)   |
| Current Draw                  | 4mA  | Weight                       | 280g   |
| Recommended Load<br>Impedance | Approximately 45 mA (static), 200 mA (maximum transient)             | Options<br>(sold separately) | 9VRechargeable Battery<br>(GIGAGAIN MIB09)   |

<sup>\*0</sup> dBu = 0.775 Vrms

<sup>\*</sup>This manual describes the product specifications at the time of the manual's release. For the latest information, please visit gigagainaudio.com