
Before using this unit, carefully read the sections entitled: "Connection Precautions" and "Battery Swap Manual"


#### **Main Features**

- Distortion pedal inspired by classic Marshall amplifiers.
- Features a Vintage/Modern toggle for two tonal ranges:
- \*Vintage: Gritty, dynamic tones reminiscent of early Marshall amps
- \*Modern: High-gain crunch characteristic of contemporary Marshall sounds

### **Panel Description**



# Battery Swap Manual



- 1. Parallelly draw out battery compartment.
- 2. Remove old battery, disconnect battery buckle clip.
- 3. Carefully observe the battery polarity (+ and -) before connecting the battery buckle clip. Connect new battery with battery buckle clip, put new battery in the compartment.
- 4. Parallelly draw in battery compartment, the magnet will help attach on the body.
- \**Tip*: you can store your picks and other small stuff in the compartment.

#### **Connection Precautions**

- Lower the volume and disconnect power to prevent misuse and equipment failure.
- Once the connections are correctly finished, please follow the subsequent steps to turn the power back on. Failure to do so may result in misuse or equipment failure
  - \* **To power on**: Connect the guitar amplifier to power last.
  - $\ensuremath{^{\star}\textit{To power off}}.$  Disconnect the guitar amplifier from power first.
- When the unit is powered ON, the indicator light displays the effect's current status:
   \*Indicator ON: Effect is active.
  - \*Indicator OFF: The unit is in bypass mode.

## **Battery Usage**

- This unit does not include a battery. Please use a 9V battery or an optional compatible power adaptor.
- If the battery power is low, the sound may become distorted. This is normal and does not indicate a malfunction. Replace the battery or connect a power adaptor.
- Always lower the volume before turning the pedal on or off. Some noise may still be heard during switching; this is normal and does not indicate a fault.
- When operating on battery power, a dim indicator light means the battery is nearly depleted.
- Replace it promptly to avoid signal interruption.
  To prevent unnecessary battery drain, switch the pedal off when not in use.

#### **Main Specifications**

| Maximum Gain                  | +35dB          | Power Supply                 | Carbon Battery (9 V, 6F22)<br>Alkaline Battery (9 V, 6LR61)<br>Power Adapter (self-supplied)<br>9V Rechargeable Battery (GIGAGAIN MIB09,<br>sold separately) |
|-------------------------------|----------------|------------------------------|--|
| Maximum Output Level          | 0dBu           |                              |  |
| Input Impedance               | 1ΜΩ            |                              |  |
| Output Impedance              | 10ΚΩ           | Dimensions                   | 116*63*37 (mm)   |
| Current Draw                  | About 15mA     | Weight                       | 320g   |
| Recommended Load<br>Impedance | 10KΩ or larger | Options<br>(sold separately) | 9VRechargeable Battery<br>(GIGAGAIN MIB09)   |

<sup>\*0</sup> dBu = 0.775 Vrms

<sup>\*</sup>This manual describes the product specifications at the time of the manual's release. For the latest information, please visit gigagainaudio.com.